

Basic RCA Stereo Connection

If you use **RCA** cable to connect the **DCT-700** to the television, Audio will be Stereo if available.

1. Use **RCA** cable (red, white and yellow) to connect to your television for a better video and audio quality.
2. Press on the **TV/VCR** or **INPUT** key on the television or remote control to select the input corresponding to where the cable is connected behind the television.

